

Fig. 1

2004-04-09 14:00:00




Fig. 2a




Fig. 2b




Fig. 3

20040101 13:00:00




Fig. 4a




Fig. 4b




Fig. 5




Fig. 6




Fig. 7




Fig.8

060340 T 03/5050




Fig. 9

Figure 1 illustrates the main menu and numeric keypad interface. The top section, labeled 72, is the "MAIN MENU" and includes navigation buttons (left and right arrows), function keys (F1, F2, F3), and action buttons (INVENTORY, ENTER, PRICE, HELP, SALE). The bottom section, labeled 74, is a numeric keypad with letters associated with numbers 1-9, a "PWR" button, a "FUNC" button, and an "ENTER" button. Below the keypad are additional navigation buttons (up and down arrows, labeled 76a and 76b) and a "SELECT" button (labeled 76c).

Fig. 10

72

<
>

F1

F2

F3

ENTER

HELP

SUBMIT ID
PLEASE RENTER ID

74

1	ABC 2	DEF 3
GHI 4	JKL 5	MNO 6
PRS 7	TUV 8	WXY 9
PWR	0	SEND
FUNC	ENTER	CLEAR

△
76a

▽
76b

SELECT

76c

76a